

Tipo (grandezza) morsa / Vise (type) size

1

2

3

4

5


6

Art. 825A

 Ghiera per morse e cubi FMS
Nut for FMS vises and cubes



Cod.	5.82.5A100	5.82.5A200	5.82.5A300	5.82.5A400	5.82.5A500	5.82.5A600

Art. 850B

 Riparo lato vite
Protection side screw



Cod.	5.85.0B100	5.85.0B200	5.85.0B300	5.85.0B400	5.85.0B500	5.85.0B600

Art. 850C

 Riparo
Protection



Cod.	5.85.0C100	5.85.0C200	5.85.0C300	5.85.0C400	5.85.0C500	5.85.0C600

Art. 850P

 Dispositivo "Terza Mano"
"Third Hand" device


Cod.	5.85.0P100	5.85.0P200	5.85.0P300	5.85.0P400	5.85.0P500	5.85.0P600

Art. 850E

 Bussola esagonale per innesto automatico
Hexagonal bushing for automatic connection


CH	12 / 22	14 / 24	19 / 30	19 / 30	27 / 40	27 / 40
Cod.	5.85.0E100	5.85.0E200	5.85.0E300	5.85.0E400	5.85.0E500	5.85.0E600

Art. 850T

 Distanziale per morsa solo autocentrante
Spacer for Self-centering vise only


Cod.	5.85.0T100	5.85.0T200	5.85.0T300	5.85.0T400	5.85.0T500	5.85.0T600

Art. 850H

 Chiave esagonale per morsa FMS e cubo
Hexagonal wrench for FMS vise and cube


Cod.	5.85.0H100	5.85.0H200	5.85.0H300	5.85.0H500

RICAMBI PER MORSE ART. 800
SPARE PARTS FOR VISES ART. 800
Art. 800E

 Guarnizione per slitta integrale
O ring for solid slide


Cod.	5.80.0E100	5.80.0E200	5.80.0E300	5.80.0E400	5.80.0E500	5.80.0E600

Art. 801G

 Grano di bloccaggio protezione centrale
Setscrew for clamping central protection


Cod.	5.80.1G100	5.80.1G200	5.80.1G300	5.80.1G400	5.80.1G500	5.80.1G600

Art. 800I

 Vite tcei per piastra di contenimento
Hex.socket head screw for screw holding plate

Art. 801H

 Vite tcei per ganasce a gradino
Hex.socket head screw for step jaws

Art. 801I

 Vite tcei per ganasce
Hex.socket head screw for jawsw

Cod.	5.80.0I100	5.80.0I200	5.80.0I300	5.80.0I400	5.80.0I500	5.80.0I600
Cod.	5.80.1H100	5.80.1H200	5.80.1H300	5.80.1H400	5.80.1H500	5.80.1H600
Cod.	5.80.1I100	5.80.1I200	5.80.1I300	5.80.1I400	5.80.1I500	5.80.1I600